

## Pickup Pen Kits Assembly Instructions


### Required Accessories:

- 7mm, Pen Mandrel
- 27/64" Drill bit RZ-DB27/64
- 2pcs Bushing Set RZ-PK14#-BU
- Use barrel trimmer RZ-PM015
- 2 Part Epoxy Glue or Insta Cure (Cyanoacrylate) Glue
- Live tailstock center




### Preparing the Blank:

- Cut 5/8" or larger square blank to the length of the brass tube (add 1/16" for trimming off)
- Drill a 27/64" hole through the blank
- Spread the glue over the tube. Insert the tube into the blank with a twisting motion to spread the glue evenly inside. Center the tube lengthwise in the blank
- When the glue dries, square off the blanks.
- You can use a barrel trimmer with the proper sleeve or a universal pen blank squaring jig with a power disc sander. Take the wood down flush with the ends of the brass tube.



### Turning the Blank:

- Mount the blank and bushings on a pen mandrel according to dia. B.
- Thread on the knurled nut and hand tighten to hold all items in place.
- Slide the tailstock snug to the mandrel shaft. (do not over tighten, it could damage the mandrel). Lock in place.
- Turn down the wood, flush with the bushings using lathe tools and gradual higher grits of sand paper.
- Finish the barrel with you choice of polish.



### Assembly:

- Layout parts according to diagram A.
- Press the lower cap into either end of any barrel.
- Press the connector into the opposite end.
- Insert the end cap into the hole in the clip.
- Insert the telescoping magnet through the opening at the barrel to bottom.
- Insert the clip assembly through the hole at the opposite end. Screw end cap into threaded hole at the end of telescoping assembly in tight.
- The Telescope Magnet is ready to use.